



- 1: Metal Stud Frame
- 2: ArmorWall™ Panel (R10, R15, or R21 Standard)
- 3: Third Party Compatible WRB
- 4: #14-13 DP1 Self Tapping Screw
- 5: Approved Sealant at Seams and Fasteners
- 6: Full Brick Veneer
- 7: Brick Tie



704-636-2411
www.maxlifeindustries.com

Mail To:
MaxLife Industries
P.O. Box 2128
Salisbury, NC 28145

MAXLIFE
INDUSTRIES
INNOVATING THE
BUILDING ENCLOSURE

Ship To:
1225 Chuck Taylor Lane
Salisbury, North Carolina 28147

DETAIL:
FULL BRICK VENEER ON ARMORWALL™ TO METAL STUD FRAME
ASSEMBLY INSIDE CORNER

NOTES:
- BUTT-JOIN ARMORWALL™ INSIDE CORNERS

SCALE:
NTS

REVISION:
01