



- 1: Concrete Masonry Unit
- 2: Damp Proofing
- 3: ArmorWall™ NP (R10, R15, or R21 Standard)
- 4: Anchor Bolt
- 5: Approved Sealant at Seams and Fasteners
- 6: Full Brick Veneer
- 7: Brick Tie



704-636-2411
www.maxlifeindustries.com

Mail To:
MaxLife Industries
P.O. Box 2128
Salisbury, NC 28145

MAXLIFE
INDUSTRIES
INNOVATING THE
BUILDING ENCLOSURE

Ship To:
1225 Chuck Taylor Lane
Salisbury, North Carolina 28147

DETAIL:
FULL BRICK VENEER ON ARMORWALL™ NP TO CONCRETE MASONRY
UNIT ASSEMBLY INSIDE CORNER

SCALE:
NTS

REVISION:
01

NOTES:
- BUTT-JOIN ARMORWALL™ NP INSIDE CORNERS
- ANCHOR BOLTS MUST BE PRE-DRILLED. ALWAYS EMBED PER FASTENER REQUIREMENTS.