



- 1: Wood Stud Frame
- 2: ArmorWall™ NP (R10, R15, or R21 Standard)
- 3: #14-13 DP1 Self Tapping Screw
- 4: Approved Sealant at Seams and Fasteners
- 5: Full Brick Veneer
- 6: Brick Tie



704-636-2411  
www.maxlifeindustries.com

Mail To:  
MaxLife Industries  
P.O. Box 2128  
Salisbury, NC 28145

**MAXLIFE**  
INDUSTRIES  
INNOVATING THE  
BUILDING ENCLOSURE

Ship To:  
1225 Chuck Taylor Lane  
Salisbury, North Carolina 28147

DETAIL:  
FULL BRICK VENEER ON ARMORWALL™ NP TO WOOD STUD FRAME  
ASSEMBLY INSIDE CORNER

NOTES:  
- BUTT-JOIN ARMORWALL™ NP INSIDE CORNERS

SCALE:  
NTS

REVISION:  
01