



- 1: Concrete Masonry Unit
- 2: Damp Proofing
- 3: ArmorWall™ VP (R10, R15, or R21 Standard)
- 4: Anchor Bolt
- 5: Approved Sealant at Seams and Fasteners
- 6: Full Brick Veneer
- 7: Brick Tie



704-636-2411  
www.maxlifeindustries.com

Mail To:  
MaxLife Industries  
P.O. Box 2128  
Salisbury, NC 28145

**MAXLIFE**  
INDUSTRIES  
INNOVATING THE  
BUILDING ENCLOSURE

Ship To:  
1225 Chuck Taylor Lane  
Salisbury, North Carolina 28147

DETAIL:  
FULL BRICK VENEER ON ARMORWALL™ VP TO CONCRETE MASONRY  
UNIT ASSEMBLY INSIDE CORNER

SCALE:  
NTS

REVISION:  
01

NOTES:  
- BUTT-JOIN ARMORWALL™ VP INSIDE CORNERS  
- ANCHOR BOLTS MUST BE PRE-DRILLED. ALWAYS EMBED PER FASTENER REQUIREMENTS.