



- 1: Metal Stud Frame
- 2: ArmorWall™ VP (R10, R15, or R21 Standard)
- 3: #14-13 DP1 Self Tapping Screw
- 4: Approved Sealant at Seams and Fasteners
- 5: Full Brick Veneer
- 6: Brick Tie



704-636-2411
www.maxlifeindustries.com

Mail To:
 MaxLife Industries
 P.O. Box 2128
 Salisbury, NC 28145

MAXLIFE
 INDUSTRIES
 INNOVATING THE
 BUILDING ENCLOSURE

Ship To:
 1225 Chuck Taylor Lane
 Salisbury, North Carolina 28147

DETAIL:
 FULL BRICK VENEER ON ARMORWALL™ VP TO METAL STUD FRAME
 ASSEMBLY INSIDE CORNER

SCALE:
 NTS

REVISION:
 01

NOTES:
 - BUTT-JOIN ARMORWALL™ VP INSIDE CORNERS