



- 1: Wood Stud Frame
- 2: ArmorWall NC (R10, R15, or R21 Standard)
- 3: #14-13 Self Tapping Screw
- 4: Approved Compatible Third Party WRB
- 5: Delta Dry and Lath Attached with #10-9 Gimlet Point Self Tapping Screw
- 6: Hard Stucco Scratch Coat
- 7: Hard Stucco Brown Coat
- 8: Hard Stucco Finish Coat



1-844-MAX4YOU
 (1-844-629-4968)
www.maxlifeindustries.com

Mail To:
 MaxLife Industries
 P.O. Box 2128
 Salisbury, NC 28145

MAXLIFE
 INDUSTRIES
 INNOVATING THE
 BUILDING ENCLOSURE

Ship To:
 4995 South Main Street
 Salisbury, North Carolina 28147

DETAIL TITLE:
 HARD COAT STUCCO ON ARMORWALL NC TO WOOD
 STUD WALL FIELD OF WALL

DETAIL NO.:

SCALE:
 NTS

REVISION:
 01

NOTES:
 - ALWAYS FOLLOW STUCCO MANUFACTURER INSTALLATION GUIDELINES.