



- 1: Concrete Structure
- 2: ArmorWall Plus Structural Insulated Sheathing (R10, R15, or R21 Standard)
- 3: #14-13 Self Tapping Screw
- 4: ArmorSeal Sealant (Gunnable Grade) at all Seams and Fasteners
- 5: Delta Dry and Lath Attached with #10-9 Gimlet Point Self Tapping Screw
- 6: Veneer Mortar
- 7: Adhered Stone Tile
- 8: Standard Pointing Mortar



1-844-MAX4YOU  
(1-844-629-4968)  
[www.maxlifeindustries.com](http://www.maxlifeindustries.com)

Mail To:  
MaxLife Industries  
P.O. Box 2128  
Salisbury, NC 28145

**MAXLIFE**  
INDUSTRIES  
INNOVATING THE  
BUILDING ENCLOSURE

Ship To:  
4995 South Main Street  
Salisbury, North Carolina 28147

DETAIL TITLE:  
ADHERED STONE TILE ON ARMORWALL PLUS TO  
CONCRETE SUBSTRATE FIELD OF WALL

DETAIL NO.:

SCALE:  
NTS

REVISION:  
01

NOTES:  
- PRE-DRILL CONCRETE SUBSTRATE PRIOR TO FASTENING ARMORWALL PER MAXLIFE INDUSTRIES FASTENER INSTRUCTIONS.  
- ALWAYS FOLLOW ADHERED STONE MASONRY INSTALLATION GUIDELINES.