



- 1: Concrete Structure
- 2: ArmorWall Plus Structural Insulated Sheathing (R10, R15, or R21 Standard)
- 3: #14-13 Self Tapping Screw
- 4: ArmorSeal Sealant (Gunnable Grade) at all Seams and Fasteners
- 5: Optional FRT Blocking
- 6: ArmorBoard Plus Return at Full Depth of Panel
- 7: Adhere Return Using (2) Beads of ArmorSeal Sealant (Gunnable Grade)
- 8: Closed Cell Backer Rod and Sealant at all Gaps Greater than 1/8" as Necessary
- 9: Approved Self-Adhered Membrane WRB at Full Depth of Punched Opening and Minimum 4" on Face of ArmorWall
- 10: Bead of ArmorSeal Sealant (Gunnable Grade) on Outer Perimeter Edge of Self-Adhered WRB



1-844-MAX4YOU
 (1-844-629-4968)
www.maxlifeindustries.com

Mail To:
 MaxLife Industries
 P.O. Box 2128
 Salisbury, NC 28145

Ship To:
 4995 South Main Street
 Salisbury, North Carolina 28147

MAXLIFE
 INDUSTRIES
 INNOVATING THE
 BUILDING ENCLOSURE

DETAIL TITLE:
 ARMORWALL PLUS TO CONCRETE SUBSTRATE
 WINDOW PUNCHED OPENING - SELF-ADHERED RETURN

DETAIL NO.:

SCALE:
 NTS

REVISION:
 01

NOTES:

- PRE-DRILL CONCRETE SUBSTRATE PRIOR TO FASTENING ARMORWALL PER MAXLIFE INDUSTRIES FASTENER INSTRUCTIONS.
- ALWAYS FOLLOW WRB MANUFACTURER INSTALLATION GUIDELINES.