



- 1: Metal Stud Frame
- 2: ArmorWall Plus Structural Insulated Sheathing (R10, R15, or R21 Standard)
- 3: #14-13 Self Tapping Screw
- 4: ArmorSeal Sealant (Gunnable Grade) at all Seams and Fasteners
- 5: ArmorWall Plus Return at Full Depth of Panel
- 6: Adhere Return Using (2) Beads of ArmorSeal Sealant
- 7: Closed Cell Backer Rod and Sealant at all Gaps Greater than 1/8" as Necessary
- 8: Approved Self-Adhered Membrane WRB at Full Depth of Punched Opening and Minimum 4" on Face of ArmorWall
- 9: Bead of ArmorSeal Sealant on Outer Perimeter Edge of Self-Adhered WRB



1-844-MAX4YOU  
 (1-844-629-4968)  
[www.maxlifeindustries.com](http://www.maxlifeindustries.com)

Mail To:  
 MaxLife Industries  
 P.O. Box 2128  
 Salisbury, NC 28145

**MAXLIFE**  
 INDUSTRIES  
 INNOVATING THE  
 BUILDING ENCLOSURE

Ship To:  
 4995 South Main Street  
 Salisbury, North Carolina 28147

DETAIL TITLE:  
 ARMORWALL PLUS TO METAL STUD FRAME WINDOW  
 PUNCHED OPENING - SELF-ADHERED RETURN

DETAIL NO.:

SCALE:  
 NTS

REVISION:  
 01

NOTES:  
 - ALWAYS FOLLOW WRB MANUFACTURER INSTALLATION GUIDELINES.