



- 1: Wood Stud Frame
- 2: ArmorWall Plus Structural Insulated Sheathing (R10, R15, or R21 Standard)
- 3: #14-13 Self Tapping Screw
- 4: ArmorSeal Sealant (Gunnable Grade) at all Seams and Fasteners
- 5: ArmorBoard Plus Return at Full Depth of Panel
- 6: Adhere Return Using (2) Beads of ArmorSeal Sealant (Gunnable Grade)
- 7: Closed Cell Backer Rod and Sealant at all Gaps Greater than 1/8" as Necessary
- 8: ArmorSeal Sealant (Brush Grade) at Full Depth of Punched Opening and Minimum 4" on Face of ArmorWall



1-844-MAX4YOU
 (1-844-629-4968)
www.maxlifeindustries.com

Mail To:
 MaxLife Industries
 P.O. Box 2128
 Salisbury, NC 28145

MAXLIFE
 INDUSTRIES
 INNOVATING THE
 BUILDING ENCLOSURE

Ship To:
 4995 South Main Street
 Salisbury, North Carolina 28147

DETAIL TITLE:
 ARMORWALL PLUS TO WOOD STUD FRAME WINDOW
 PUNCHED OPENING - LIQUID-APPLIED RETURN

DETAIL NO.:

SCALE:
 NTS

REVISION:
 01

NOTES: