



- 1: Metal Stud Frame
- 2: ArmorWall Plus Structural Insulated Sheathing (R10, R15, or R21 Standard)
- 3: #14-13 Self Tapping Screw
- 4: ArmorSeal Sealant at all Seams and #14-13 Self Tapping Screws
- 5: Hohmann & Barnard Adjusto-Tie Adjustable Veneer Anchor
- 6: Full Brick and Mortar Veneer



1-844-MAX4YOU  
 (1-844-629-4968)  
[www.maxlifeindustries.com](http://www.maxlifeindustries.com)

Mail To:  
 MaxLife Industries  
 P.O. Box 2128  
 Salisbury, NC 28145

Ship To:  
 4995 South Main Street  
 Salisbury, North Carolina 28147

**MAXLIFE**  
 INDUSTRIES  
 INNOVATING THE  
 BUILDING ENCLOSURE

DETAIL TITLE:  
 FULL BRICK AND MORTAR VENEER ON ARMORWALL  
 PLUS TO METAL STUD FRAME FIELD OF WALL

DETAIL NO.:

SCALE:  
 NTS

REVISION:  
 01

NOTES:  
 - MAINTAIN REQUIRED BRICK TIE SPACING SUBSTITUTING WITH #14-13 DP1 SELF TAPPING SCREWS WHERE NECESSARY.  
 - IT IS NOT NECESSARY TO APPLY ARMORSEAL SEALANT TO ADJUSTO-TIE VENEER ANCHORS.