



- 1: Concrete Masonry Unit
- 2: ArmorWall Plus Structural Insulated Sheathing (R10, R15, or R21 Standard)
- 3: #14-13 Self Tapping Screw
- 4: ArmorSeal Sealant (Gunnable Grade) at all Seams and Fasteners
- 5: Furring Strips Attached with #10-9 Gimlet Point Self Tapping Screw
- 6: Fiber Cement Lap Siding



1-844-MAX4YOU  
 (1-844-629-4968)  
[www.maxlifeindustries.com](http://www.maxlifeindustries.com)

Mail To:  
 MaxLife Industries  
 P.O. Box 2128  
 Salisbury, NC 28145

Ship To:  
 4995 South Main Street  
 Salisbury, North Carolina 28147

**MAXLIFE**  
 INDUSTRIES  
 INNOVATING THE  
 BUILDING ENCLOSURE

DETAIL TITLE:  
 FIBER CEMENT LAP SIDING ON ARMORWALL PLUS TO  
 CONCRETE SUBSTRATE FIELD OF WALL

DETAIL NO.:

SCALE:  
 NTS

REVISION:  
 01

NOTES:  
 - PRE-DRILL CONCRETE SUBSTRATE PRIOR TO FASTENING ARMORWALL PER MAXLIFE INDUSTRIES FASTENER INSTRUCTIONS.  
 - ALWAYS FOLLOW FIBER CEMENT LAP SIDING MANUFACTURER INSTALLATION GUIDELINES.