



- 1: Metal Stud Frame
- 2: ArmorWall VP (R10, R15, or R21 Standard)
- 3: #14-13 Self Tapping Screw
- 4: ArmorSeal Sealant at all Seams and #14-13 Self Tapping Screws
- 5: Hohmann & Barnard Adjusto-Tie Adjustable Veneer Anchor
- 6: Full Brick and Mortar Veneer



1-844-MAX4YOU
 (1-844-629-4968)
www.maxlifeindustries.com

Mail To:
 MaxLife Industries
 P.O. Box 2128
 Salisbury, NC 28145

MAXLIFE
 INDUSTRIES
 INNOVATING THE
 BUILDING ENCLOSURE

Ship To:
 4995 South Main Street
 Salisbury, North Carolina 28147

DETAIL TITLE:
 FULL BRICK AND MORTAR VENEER ON ARMORWALL
 VP TO METAL STUD FRAME FIELD OF WALL

DETAIL NO.:

SCALE:
 NTS

REVISION:
 01

NOTES:
 - MAINTAIN REQUIRED BRICK TIE SPACING SUBSTITUTING WITH #14-13 DP1 SELF TAPPING SCREWS WHERE NECESSARY.
 - IT IS NOT NECESSARY TO APPLY ARMORSEAL SEALANT TO ADJUSTO-TIE VENEER ANCHORS.