



- 1: Wood Stud Frame
- 2: ArmorWall VP (R10, R15, or R21 Standard)
- 3: #14-13 DP1 Self Tapping Screw
- 4: ArmorSeal Sealant at all Seams and Fasteners
- 5: Hohmann & Barnard DW-10 Brick Tie
- 6: Butt Joint Inside Corner
- 7: Full Brick and Mortar Veneer



1-844-MAX4YOU
 (1-844-629-4968)
www.maxlifeindustries.com

Mail To:
 MaxLife Industries
 P.O. Box 2128
 Salisbury, NC 28145

MAXLIFE
 INDUSTRIES
 INNOVATING THE
 BUILDING ENCLOSURE

Ship To:
 4995 South Main Street
 Salisbury, North Carolina 28147

DETAIL:
 FULL BRICK AND MORTAR VENEER ON ARMORWALL VP TO WOOD
 STUD FRAME INSIDE CORNER

SCALE:
 NTS

REVISION:
 01

NOTES: