



- 1: Metal Stud Frame
- 2: ArmorWall VP (R10, R15, or R21 Standard)
- 3: #14-13 DP1 Self Tapping Screw
- 4: ArmorSeal Sealant at all Seams and Fasteners
- 5: Butt Joint Inside Corner
- 6: Hat Channel
- 7: Cladding System Clip
- 8: Metal Wall Panel



1-844-MAX4YOU  
 (1-844-629-4968)  
[www.maxlifeindustries.com](http://www.maxlifeindustries.com)

Mail To:  
 MaxLife Industries  
 P.O. Box 2128  
 Salisbury, NC 28145

**MAXLIFE**  
 INDUSTRIES  
 INNOVATING THE  
 BUILDING ENCLOSURE

Ship To:  
 4995 South Main Street  
 Salisbury, North Carolina 28147

DETAIL:  
 METAL WALL PANEL ON ARMORWALL VP TO METAL STUD FRAME  
 INSIDE CORNER

SCALE:  
 NTS

REVISION:  
 01

NOTES:  
 - ALWAYS FOLLOW METAL WALL PANEL SYSTEM MANUFACTURER INSTALLATION GUIDELINES.