



- 1: Concrete Structure
- 2: ArmorWall VP (R10, R15, or R21 Standard)
- 3: #14-13 Self Tapping Screw
- 4: ArmorSeal Sealant (Gunnable Grade) at all Seams and Fasteners
- 5: Inverted Hat Cladding Mount Fastened with #10-9 Gimlet Point Self Tapping Screw
- 6: Inverted Zee Cladding Mount Fastened with #10-9 Gimlet Point Self Tapping Screw
- 7: Mechanically Fastened Exposed Fastener (EF) Cladding Panels



1-844-MAX4YOU
 (1-844-629-4968)
www.maxlifeindustries.com

Mail To:
 MaxLife Industries
 P.O. Box 2128
 Salisbury, NC 28145

MAXLIFE
 INDUSTRIES
 INNOVATING THE
 BUILDING ENCLOSURE

Ship To:
 4995 South Main Street
 Salisbury, North Carolina 28147

DETAIL TITLE:
 EF PANEL CLADDING ON ARMORWALL VP TO
 CONCRETE SUBSTRATE FIELD OF WALL

DETAIL NO.:

SCALE:
 NTS

REVISION:
 01

NOTES:
 - PRE-DRILL CONCRETE SUBSTRATE PRIOR TO FASTENING ARMORWALL PER MAXLIFE INDUSTRIES FASTENER INSTRUCTIONS.
 - ALWAYS FOLLOW CLADDING MANUFACTURER INSTALLATION GUIDELINES.